

IMPORTANT INFORMATION: HOW TO INSTALL MIRRORS



We will not accept any claims for defective sides or corners in mirrors that have already been installed! Before removing the mirror from its packaging, make sure that the surface on which it will be placed is soft enough. Lay the mirror with extreme caution. The slightest contact of the corners of the mirror with a hard surface inevitably leads to glass chipping.



THE BELOW WAS INSPECTED BEFORE SHIPPING

Electronics

Sides/corners

Installing material

Instructions

Artelinea manufactures all its products in compliance with the highest quality standards. To produce this mirror, only certified materials suitable for use in bathroom furnishings were used.

This product has passed all visual and mechanical tests and has been approved for usage.

Serial number (SN): _____

**FREE WARRANTY
EXTENSION:**

<https://www.artelinea.it/warranty>




BEFORE INSTALLING CHECK THE FOLLOWING

Check the mirror for damage BEFORE installing (also under the edge protections and any stickers)!

Is something damaged? DO NOT INSTALL THE MIRROR!


Immediately take some photos (including packaging and any labels) and contact your dealer. Always indicate the serial number shown above.

Hang the mirror only on the supplied device and never on the external frame! Make sure, by moving the mirror sideways, that it is locked in the bracket.



NOTES ON WALL MOUNTING

Hang the mirror only on the supplied device and never on the external frame! Make sure, by moving the mirror sideways, that it is locked in the bracket.



WALL MOUNTING

<https://www.artelinea.it/files/wallmount.mp4>



SCREWS TO BE USED

Wooden walls:

Use the screw WUEPOFAST TPS Z2 ZN B 5,0X40/34
(WURTH cod. 019865 40 005 500)



Plasterboard walls:

Use the self-drilling dowel WURTH model W-GS type Z/L (WURTH cod. 0903 253 1) combined with WURTH cod. 0198645 50



Walls in C20 / 25 concrete, solid bricks, C4 spun concrete and hollow bricks:

Use the nylon plug WURTH model W-MR complete with galvanized TMT chipboard screw 5,0x45mm (WURTH cod. 0903 275 8)



MAINTENANCE AND REMOVAL OF ADHESIVE

- Never use aggressive cleaning agents!
- Never use abrasive products!
- Clean the mirror with a soft cloth and white alcohol. The mirror should always be rubbed with a dry cloth after each cleaning or in case of high humidity to avoid dripping residues on the edges, which can damage the coating in the long run.
- Remove stubborn residue with a cleaning blade.

CLEANING BLADE

<https://www.artelinea.it/files/removeadhesive.mp4>

