

ARTELINEA

FIRENZE 1962

ARTELINEA S.p.A. – Via dell'Industria 1, loc. S. Barbara, 52022 Cavriglia (AR) – WWW.ARTELINEA.IT – info@artelina.it

Dear customer, please read the following recommendations very carefully before of installing the Artelina glass tiles. In addition to the illustrated description, we have prepared also a demonstrative [video](#) to guide you step by step. Please note that glass tiles are very sensitive products that should be only installed by professional and very experienced personnel. If you have no experience with cutting and drilling tiles, please consider that Artelina can do this work for you in advance for an additional charge.



<https://youtu.be/iu2GbdHgf0c>



Before you start installing the tiles, make sure that the wall is absolutely straight.

Apply the cement/adhesive to the wall as well as to the tiles. Be careful to avoid any bubbles and tension during its application to the wall.

VIDEO: 0:00 - 2:46



After aligning the tiles, wait until the cement / adhesive has dried out. This will take in the most of cases at least 24 hours but varies depending on the used product, temperature etc.

Make sure to read the cement's / adhesive's instructions very carefully before applying it to the wall and the tiles.

VIDEO: 2:46 - 2:52



Mark the holes that you will need to drill directly onto the glass tiles.

VIDEO: 2:53 - 2:59



It is very important to avoid any pressure between the screws and glass tiles. The hole in the glass has always to exceed the hole in the masonry by at least 2mm in its diameter or more.

If the needed screws and dowels come with a diameter of 8mm then the glass should be drilled with at least 10mm.

Important: The drill and glass must be cooled down with water during drilling to avoid thermal shocks / overheating!

VIDEO: 3:00 - 3:55



When drilling into the wall, make sure to keep the drill always perfectly straight otherwise, small cracks could form when touching the glass, which can later strongly affect its integrity.

Additional advice (not shown in the video): To increase safety, you can cover the inside of the drilled glass tile with a thin insert made out of plastic while you drill the wall.

VIDEO: 3:55 - 4:37



To avoid any pressure on the glass tile, the dowels must be pushed into the wall until they are in line with the flush with the masonry.

Additional advice (not shown in the video): If you use any supplied screws and dowels, make always sure that their function can be still guaranteed, as the additional distance must be taken into account.

VIDEO: 4:38 - 5:29



Do not over tighten the screws to avoid any pressure on the glasses surface. The screws and dowels should never touch the glass inside of the drilling.

Additional advice (not shown in the video): Depending on the type of suspension used, we recommend fitting it with a wafer-thin rubber pad to avoid possible pressure points.

VIDEO: 5:30 - 6:10

When aligning furniture, mirrors etc., it is important that the weight, especially in the area of the holes, never presses directly on the glass tiles, but it is very important to distribute it equally over the complete surface.

The screws in the masonry always hold the weight, never by the glass tiles themselves.

Video: 6:11 - 7:10

Disclaimer: Artelinea does not take any responsibility for the above given information. Damages caused by any kind of modification to our products are not covered by our warranty terms.

HOW TO CUT A GLASS TILE:
<https://youtu.be/V01gPUE1Up4>



HOW TO DRILL A GLASS TILE:
<https://youtu.be/DI-oWcrWiYY>



Per domande **CONTATTARE** - For any issues please **CONTACT**
Para otras consultas **CONTACTAR** - Pour toute assistance **CONTACTER**
Bei weiteren Fragen kontaktieren Sie bitte

ARTELINEA
FIRENZE 1962
T +39 055 961 961
info@artelinea.it